



# 2305-001 Precision MAPS Positioners

---



## User Manual

PN: 1744193

July, 2021

Rev A

ETS-Lindgren Inc. reserves the right to make changes to any products herein to improve functioning or design. Although the information in this document has been carefully reviewed and is believed to be reliable, ETS-Lindgren does not assume any liability arising out of the application or use of any product or circuit described herein; nor does it convey any license under its patent rights nor the rights of others. All trademarks are the property of their respective owners.

© Copyright 2021 by ETS-Lindgren Inc. All Rights Reserved. No part of this document may be copied by any means without written permission from ETS-Lindgren Inc.

Trademarks used in this document: The ETS-Lindgren logo is a registered trademark of ETS-Lindgren, Inc. *Microsoft* and *Windows* are registered trademarks of Microsoft Corporation.

Revision Record  
MANUAL, 2305-001 | Part #1744193 Rev A

Revision	Description	Date
A	Initial Release	July, 2021




# TABLE OF CONTENTS

---

NOTES, CAUTIONS AND WARNINGS	4
SAFETY INFORMATION	5
INTRODUCTION	6
2305-001 Precision MAPS Positioner Standard Assembly.....	6
ETS-Lindgren Product Information Bulletin.....	6
MAINTENANCE	8
Routine Maintenance .....	8
6-Month Service .....	8
Safety Precautions.....	8
Service Procedures.....	8
Replacement Parts .....	9
SPECIFICATIONS	10
Physical Specifications .....	10
Electrical Specifications.....	10
INSTALLATION	11
Securing the Positioner Base.....	11
Electrical Installation.....	11
Attaching Absorber.....	11
MOUNTING THE EUT	12
Securing the EUT.....	12
Adjusting the Linear Slide .....	12
Input / Output Connections.....	13
Trigger .....	13
Reset .....	13
Fiber Optic .....	13
OPERATION	14
2305-001 Precision MAPS Positioner Command Set .....	15
System Commands .....	16
Control Commands.....	17
Error Codes .....	22
NETWORK CONFIGURATION	23
Network Factory Configuration.....	23
Changing the Positioner IP Address.....	23
Reset to Factory Default.....	24
Computer Network Configuration.....	25
Background Information.....	26
Multiple Devices in a LAN .....	30

## NOTES, CAUTIONS AND WARNINGS

---













	<b>Note:</b> Denotes helpful information intended to provide tips for better use of the product.
	<b>CAUTION:</b> Denotes a hazard. Failure to follow instructions could result in minor personal injury and/or property damage. Included text gives proper procedures.
	<b>WARNING:</b> Denotes a hazard. Failure to follow instructions could result in <b>SEVERE</b> personal injury and/or property damage. Included text gives proper procedures.

\*All notes, cautions, and warnings will be located on the left column area of the page.



See the ETS-Lindgren **Product Information Bulletin** for safety, regulatory, and other product marking information

## SAFETY INFORMATION

	<p>See the ETS-Lindgren <i>Product Information Bulletin</i> for safety, regulatory, and other product marking information.</p>
	<p><b>Refer to Manual:</b> When product is marked with this symbol, see the instruction manual for additional information. Manuals are available for download at ets-lindgren.com, or contact ETS-Lindgren Technical Support.</p>
	<p><b>High Voltage:</b> Indicates presence of hazardous voltage. Unsafe practice could result in severe personal injury or death.</p>
	<p><b>Only qualified personnel</b> should operate (or service) this equipment. The electrical installation of this product should be accomplished by an individual who is authorized to so do by the appropriate local authority. The installation should be in compliance with local electrical safety codes.</p>
	<p><b>Heavy Object:</b> Unassisted lifting can cause injury. Mechanical assistance is required.</p>
	<p><b>Stay clear</b> of moving components during operation of equipment.</p>
	<p>Moving and/or falling equipment can cause serious injury.</p>
	<p><b>Keep hands clear:</b> Moving parts can crush and cut.</p>
	<p><b>Pinch Points:</b> Keep hands clear during operation.</p>
	<p><b>Moving Gears:</b> Do not stick hand in or near machine during operation.</p>
	<p><b>Do not make any modifications to this unit without consulting the factory directly.</b></p> <p><b>Before servicing:</b> Contact ETS-Lindgren. Servicing (or modifying) the unit by yourself may void your warranty. If you attempt to service the unit by yourself, disconnect all electrical power before starting. There are voltages at many points in the instrument which could, if contacted, cause personal injury. Only trained service personnel should perform adjustments and/or service procedures upon this instrument. Capacitors inside this instrument may still be charged even when instrument is disconnected from its power source.</p>
	<p><b>Protective Earth Ground (Safety Ground):</b> Indicates protective earth terminal. You should provide uninterruptible safety earth ground from the main power source to the product input wiring terminals, power cord, or supplied power cord set.</p> <p>Before power is applied to this instrument, ground it properly through the protective conductor of the AC power cable to a power source provided with the protective earth contact. Any interruption of the protective (grounding) conductor, inside or outside the instrument, or disconnection of the protective earth terminal could result in personal injury.</p>



**Note:**

See the ETS-Lindgren *Product Information Bulletin* for safety, regulatory, and other product marking information.



**Note:**

ETS-Lindgren may substitute a similar part or new part number with the same functionality for another part/part number. Contact ETS-Lindgren for questions about part numbers and ordering parts.



Only qualified personnel should operate (or service) this equipment. If you have any questions concerning maintenance, contact ETS-Lindgren Technical Support. Warranty may be voided if housing is opened.

**CAUTION**

Before performing any maintenance, read the safety information in the ETS-Lindgren *Product Information Bulletin* included with your shipment.

## INTRODUCTION

The ETS-Lindgren 2305-001 Precision MAPS Positioner, is designed to perform automated 3-dimensional pattern measurements. The positioner includes a vertical column that will accommodate equipment under test (EUT) up to 22.05 lbs (10 kg).

The 2305-001 provides independent rotation in both horizontal and vertical axis. An IEC receptacle is the standard power input. The IEC rocker switch illuminates red when in the ON position. The positioner is controlled over Ethernet software installed on a control computer.

### 2305-001 Precision MAPS Positioner Standard Assembly

- Single-phase electric drive (240 VAC 50/60 Hz)
- Control Enclosure
- 8- 2.92 mm RF Connectors
- 4- SMA Connectors
- DC Power Line
- Absorber
- Cables

### ETS-Lindgren Product Information Bulletin

See the ETS-Lindgren *Product Information Bulletin* included with your shipment for the following:

- Safety, regulatory, and other product marking information
- Steps to receive your shipment
- Steps to return a component for service
- ETS-Lindgren calibration service
- ETS-Lindgren contact information

**WARNING**



**Heavy Object:**

Unassisted lifting can cause injury. Mechanical assistance is required.

**WARNING**



Electrical installation must be performed by a qualified electrician, and in accordance with local and national electrical standards.



Stay clear of all moving components.



**Keep hands clear:**

Moving parts can crush and cut.





**Pinch Points:**

Keep hands clear during operation.



**Moving Gears:**

Do not stick hand in or near machine during operation.



Phi Axis Motor

Wireway

Turntable

Rear View



**Note:**

See the ETS-Lindgren *Product Information Bulletin* for safety, regulatory, and other product marking information.

**WARNING**

Before assembling, installing, or connecting any components, follow the safety information in the ETS-Lindgren *Product Information Bulletin* included with your shipment.



**Note:**

Contact ETS-Lindgren Technical Support for assistance with replacement parts.



Only qualified personnel should operate (or service) this equipment. If you have any questions concerning maintenance, contact ETS-Lindgren Technical Support. Warranty may be voided if housing is opened.

## MAINTENANCE

Routine maintenance should be conducted prior to each use of the turntable. For assistance, contact ETS-Lindgren Technical Support.

### Routine Maintenance

- **Check absorber for damage.** Contact ETS-Lindgren to replace any damaged absorber.
- **Check for excessive rotation.** Attempt to rotate the turntable top by hand. Excessive rotation may indicate a loose drive component.
- **Listen for excessive noise.** Listen for excessive or unusual noise during turntable operation.
- **Check cables for wear.** Ensure they are clear of potential damage from moving parts.
- **Select Phi axis homing direction based on cable orientation.** Cables can tangle, disconnect, and rip if the Phi axis is set to home in the wrong direction.

### 6-Month Service

- **Lubricate the casters.** Lubricate the casters with good quality bearing grease.

### Safety Precautions

- Removing top panel will expose AC power.
- Do not use damaged or crimped AC power cords.
- Do not connect or disconnect cables while power is on.

### Service Procedures

For the steps to return a system or system component to ETS-Lindgren for service, see the *Product Information Bulletin* included with your shipment or contact ETS-Lindgren Technical Support.



**WARNING**



**High Voltage:**  
Unsafe practice could result in severe personal injury or death.

**CAUTION**



Disconnect the power before proceeding with recommended maintenance. Do not perform maintenance while the positioner is operating.



Stay clear of all moving components.

**WARNING**




Moving and/or falling equipment can cause serious injury.

**Replacement Parts**

There are no user serviceable parts on this assembly. For assistance, contact ETS-Lindgren Technical Support. The following items are the part numbers for ordering replacement parts.

Part Description	Part Number
Absorber	1739178
Absorber	1739179
Absorber	1739182
Absorber	1739183
Absorber	1739184
Absorber	1739185
Absorber	1739186
Absorber	1737583
Absorber	1737584
Absorber	1739180
Cable Kit	1739187
Fiber-Ethernet Converter Kit	120255
Fiber Optic Cable Duplex	705347-10
Fiber Optic to Ethernet Converter	708043
CAT-5E Cable, 3'	257111
NEMA Cordset	670024
Cable, RF 40 GHz 2.92(M)-2.92(M)	1742086



# SPECIFICATIONS

## WARNING



### Heavy Object:

Unassisted lifting can cause injury. Mechanical assistance is required.



Only qualified personnel should operate (or service) this equipment. If you have any questions concerning maintenance, contact ETS-Lindgren Technical Support. Warranty may be voided if housing is opened.

## WARNING



### High Voltage:

Unsafe practice could result in severe personal injury or death.

## CAUTION

### Damaged or crimped AC cords:


Using damaged or crimped AC cords may damage the equipment and/or cause physical injury.

## Physical Specifications

Chamber Center Line Height:	60 in (152.40 cm)
Turntable Diameter:	50 in (127.00 cm)
Height:	68.13 in (173.05 cm)
Turntable Diameter with Absorber	52 in (132.08 cm)
Maximum Load Capacity:	22.05 lbs (10 kg)
Shipping Weight:	894 lbs (405.51 kg)

## Electrical Specifications

Phase:	1
Voltage:	240
Amperage:	10



# INSTALLATION

## WARNING

Before assembling, installing, or connecting any components, follow the safety information in the ETS-Lindgren Product Information Bulletin included with your shipment.

## WARNING



### High Voltage:

Unsafe practice could result in severe personal injury or death.

## WARNING



Electrical installation must be performed by a qualified electrician, and in accordance with local and national electrical standards.

## CAUTION



Disconnect power before proceeding.

## CAUTION


Other than during installation, do not touch absorber. Skin oils and other debris can damage and discolor the foam.

The positioner will be assembled by ETS-Lindgren. Following are instructions for preparing the positioner for use.

## Securing the Positioner Base

Required:

- Power drill with socket bit or impact/hammer drill
  - Vacuum
  - M6 (25 mm) stainless steel hex head self-drilling screws.
  - Do not use any screws other than M6.
1. Uncrate all parts. check all parts for any shipping damage.
  2. Gather all included M6 self-drilling screws.
  3. Mark off desired area in chamber for positioner.
  4. Align base to markings.
  5. With power drill, use screws to mount the positioner to the chamber floor through the holes in the base.
  6. Vacuum any debris left from drilling.



Holes for Securing to Floor

## Electrical Installation

Make sure the power is off before proceeding.

Connect the fiber optic control cable and install the power connection according to local electrical code.

## Attaching Absorber

Absorber should be attached to the exterior of the turntable, and should be replaced if damaged. The absorber part numbers are provided in *Replacement Parts*, page 9.

Using the hook and loop side, attach the absorber on the positioner.

## WARNING

Before assembling, installing, or connecting any components, follow the safety information in the ETS-Lindgren Product Information Bulletin included with your shipment.

## WARNING

Do not operate the positioner with the linear slide unlocked. Doing so may damage equipment and/or cause injury.



Stay clear of all moving components.



### Keep hands clear:

Moving parts can crush and cut.



### Pinch Points:

Keep hands clear during operation.




### Moving Gears:

Do not stick hand in or near machine during operation.


## MOUNTING THE EUT

### Securing the EUT

1. Thread M6 screws through the openings to attach EUT to the rail clamp on the Phi axis. The max load capacity is 22.05 lbs (10 kg).
2. Connect the cables through the opening between the adjustable rails.



EUT Cabling on Phi Axis




EUT cables are included. The configuration of EUT cables is dependent upon specific test situations.


### Adjusting the Linear Slide

Use the linear slide to align the EUT according to the applicable standard. The linear slide is manually adjustable.


1. Adjust the linear slide using the handwheel located at the base of the Phi axis.
2. Lock the slide in place using the guide clamp on the side of the slide carrier. Do not operate the positioner with the linear slide unlocked.



Handwheel



Guide Clamp





Only qualified personnel should operate (or service) this equipment. If you have any questions concerning maintenance, contact ETS-Lindgren Technical Support. Warranty may be voided if housing is opened.

**WARNING**



**High Voltage:**  
Unsafe practice could result in severe personal injury or death.

**WARNING**



Electrical installation must be performed by a qualified electrician, and in accordance with local and national electrical standards.

**WARNING**



Moving and/or falling equipment can cause serious injury.

## Input / Output Connections

### Trigger


The positioner is equipped with a TTL-compatible output. This output is capable of driving a 50 ohm load that can be used to trigger a measurement sweep on a network analyzer (or other measurement device equipped with a TTL-compatible external trigger input option).

### Reset

Pressing Reset for more than 6 seconds resets the device IP address and mask to factory default, 192.168.0.100, 255.255.255.0. (Used in case the IP address of the device is unknown.)

### Fiber Optic

The positioner is equipped with a fiber-optic inlet and a fiber-optic outlet. Connect the positioner to the included Ethernet-to-fiber optic converter using the included dual fiber optic cable with type ST connections. The converter connects to the host computer via the included 0.9 m (3.0 ft) Cat5 Ethernet cable. Ensure the fiber converter TX line is connected to the positioner RX input connector, and the fiber converter RX line is connected to the positioner TX output connector.



Connector Panel

## OPERATION

Firmware is installed in the positioner, and it is controlled by PC.

### WARNING



#### High Voltage:

Unsafe practice could result in severe personal injury or death.



Stay clear of all moving components.



#### Keep hands clear:

Moving parts can crush and cut.



#### Pinch Points:

Keep hands clear during operation.



#### Moving Gears:

Do not stick hand in or near machine during operation.

### CAUTION

#### Damaged or crimped AC cords:

Using damaged or crimped AC cords may damage the equipment and/or cause physical injury.

### CAUTION


Read this manual completely before operating. Before and during operation, follow the safety information in the ETS-Lindgren Product Information Bulletin included with your shipment.

### WARNING

Ensure the current travel limit settings will not cause damage to existing cables.

### WARNING

Do not operate the Precision MAPS Positioner in a stalled condition. Doing so can cause damage to the drive unit and will void the warranty. Ensure the positioner will continue to rotate under load at all speeds.



## 2305-001 Precision MAPS Positioner Command Set

The turntable is unlimited in its rotation. Axis 2 rotates from 0° to 360°.

### 2305-001 Speeds (for all axes)

Min Speed: 0.25 RPM

Max Speed: 12 RPM

Default speed settings

S RPM

1 1.0

2 2.0

3 3.0

4 4.0

5 5.0

6 6.0

7 7.0

8 8.0



The following command set is general and includes commands that may not apply to your specific positioner. Speeds listed in this generic list are representative only.

### General Command Structure

Most of the following commands use this general structure:

[**AXIS**<n[-m]>:]**COMMAND** <argument\_n>[,<argument\_m>]

Where:

[ ]	Indicates optional.
< >	Indicates required.
<b>COMMAND</b>	The backwards compatible Model 2090 Multi Device Controller command. When used by itself, controls the first device in a multi axis system, and, when arguments are required, supports only a single argument.
<b>The command prefix in optional brackets [ ]</b> <b>[<b>AXIS</b>&lt;n[-m]&gt;:]<b>COMMAND</b> &lt;argument_n&gt;[,&lt;argument_m&gt;]</b>	Required to access a specific axis or multiple axes at a time. Selects the desired axis or axes to control. A single index specifies a single axis (e.g. <b>AXIS1</b> or <b>AXIS2</b> ) with a single argument, while a range (e.g. <b>AXIS1-2</b> ) specifies a range of axes with a corresponding range of arguments. Note that some commands only support single axis control.
<argument_n>	The single argument required for a single axis command.
[,<argument_m>]	Represents the additional arguments required for an optional multi-axis command (e.g. <b>AXIS1-2:COMMAND 1,2</b> ).



## System Commands

Device Identification Query	
<b>Command:</b>	*IDN?
<b>Description:</b>	Identification query. Determines the nature of device located at a given address on the network. The string returned ("ETS-Lindgren Inc.,2303 Precision Positioner,<Module Name>,PCA120518 FW N.NN") identifies this device as a 2303 Precision Positioner. The <Module Name> parameter is a place holder to identify a specific module. The N.NN parameter is a place holder for the firmware version identification.
<b>Query:</b>	*IDN?
<b>Returns:</b>	ETS-Lindgren Inc.,2303 Precision Positioner,<Module Name>,PCA120518 FW n.nn
<b>Example:</b>	*IDN? ETS-Lindgren Inc.,2303 Precision Positioner,Comm,PCA120518 FW 4.14

Module IP Address	
<b>Command:</b>	MOD:IP <nnn.nnn.nnn.nnn>
<b>Description:</b>	The device default IP address and subnet mask is 192.168.0.100, 255.255.255.0. The default address and subnet mask are assigned to the device by ETS-Lindgren and do not change even if your computer reboots. The IP address can be changed using the MOD:IP command. The port number is 1206.
<b>Query:</b>	MOD:IP?
<b>Returns:</b>	nnn.nnn.nnn.nnn
<b>Example:</b>	MOD:IP 192.168.0.55

Module Name	
<b>Command:</b>	MOD:NAME <Module Name>
<b>Description:</b>	The <Module Name> parameter in the *IDN? query response is a place holder to identify a specific device in a network. If you have more than one device you might want to identify them with different module names. For instance, "EMC LAB1" and "EMC CHAMBER".
<b>Query:</b>	MOD:NAME?
<b>Example:</b>	MOD:NAME EMC LAB1

Module Subnet Mask	
<b>Command:</b>	MOD:NETMASK <nnn.nnn.nnn.nnn>
<b>Description:</b>	The device default IP address and subnet mask is 192.168.0.100, 255.255.255.0. This address and mask are assigned to the device by ETS-Lindgren and does not change even if your computer reboots. The subnet mask can be changed using the MOD:NETMASK command. The new subnet mask will not change even if your computer reboots.
<b>Query:</b>	MOD:NETMASK?
<b>Returns:</b>	nnn.nnn.nnn.nnn
<b>Example:</b>	MOD:NETMASK 255.255.0.0



## Control Commands

Acceleration in Milliseconds	
<b>Command:</b>	A <nnnn>
<b>Description:</b>	Acceleration setting for variable speed devices. The number nnnn represents the time in milliseconds for the positioner to reach max speed. For high inertial loads, a longer acceleration time might be required.
<b>Query:</b>	A?
<b>Returns:</b>	The time in milliseconds for the positioner to reach max speed.
<b>Example:</b>	AXIS1:A 1000

Acceleration in Seconds	
<b>Command:</b>	ACC nn.n
<b>Description:</b>	Acceleration setting for variable speed devices. The number N.N represents the time in seconds for the positioner to reach max speed. For high inertial loads, a longer acceleration time might be required.
<b>Query:</b>	ACC?
<b>Returns:</b>	The time in seconds for the positioner to reach max speed.
<b>Example:</b>	AXIS2:ACC .5

Command Complete Query	
<b>Command:</b>	*OPC?
<b>Description:</b>	Informs if a seek or home command have been completed. Please see home command for an example of how to use the *OPC query.
<b>Query:</b>	*OPC?
<b>Returns:</b>	1 if a seek or home command have been completed, 0 otherwise.
<b>Example:</b>	AXIS3:*OPC?

Current Position	
<b>Command:</b>	CP nn.n
<b>Description:</b>	Changes the current position of the device. When editing limits or the current position setting, the software will not allow the current position to be set outside the software limits, nor can the upper or lower limits be adjusted below or above, respectively, the current position or each other.
<b>Example:</b>	AXIS1:CP 90
<b>Query:</b>	CP?
<b>Returns:</b>	Axis current position The value returned is either in XXX.X or XXX.XX format. Negative values are preceded by a "-" minus sign. Linear positioners return current position in centimeters, turntables return it in degrees..
<b>Example:</b>	AXIS1-3:CP? Response 10.5, -90.0, 70.0

Error Query	
<b>Command:</b>	ERR?
<b>Description:</b>	Queries the axis error register. The error register is cleared on read.
<b>Query:</b>	ERR?
<b>Returns:</b>	An error code (See list at the end of command set.)
<b>Example:</b>	AXIS3:ERR?

Homing Procedure	
<b>Command:</b>	HOME
<b>Description:</b>	<p>The device has a mechanical home sensor. Every time the positioner is turned on, a home procedure must be performed so the current position is known by the firmware. To home the positioner, send the following commands:</p> <pre>HOME *OPC?</pre> <p>Keep querying the positioner by sending the *OPC? until it returns 1.  *OPC? Will return 0 if the turntable is still being homed.  *OPC? will return 1 if the home procedure is done.</p> <p>After *OPC returns 1, send the query HOME? to confirm that the positioner found the mechanical home sensor.  HOME? returns 0 if the home procedure was not successful; result of a faulty sensor.</p>
<b>Query:</b>	HOME?
<b>Returns:</b>	1 if the AXIS1 has been homed, 0 otherwise
<b>Example:</b>	AXIS1:HOME

Lower Limit	
<b>Command:</b>	LL nnn.n
<b>Description:</b>	Sets the lower/counterclockwise limit of the device. The specified value nnn.n must be less than the upper/clockwise limit.
<b>Query:</b>	LL?
<b>Returns:</b>	Lower or counterclockwise limit of the device in degrees.
<b>Example:</b>	AXIS1-2:LL 0,-10

Motion Direction	
<b>Command:</b>	DIR?
<b>Description:</b>	Queries the motion direction for the device.
<b>Query:</b>	DIR?
<b>Returns:</b>	<p>&lt;direction&gt; Value indicating the current motion of the queried device.</p> <pre>+1      Device is moving up/clockwise. 0       Device is stopped. -1     Device is moving down/counterclockwise</pre>
<b>Example:</b>	AXIS1-2:DIR? Response: 0,+1

Move Clockwise	
<b>Command:</b>	CW
<b>Description:</b>	Instructs the positioner to move in the clockwise direction. In non-continuous mode this movement is limited by the clockwise (upper) limit.
<b>Example:</b>	AXIS1-2:CW
Move Counterclockwise	
<b>Command:</b>	CCW
<b>Description:</b>	Instructs the positioner to move in the counterclockwise direction. This movement is limited by the counterclockwise (lower) limit.
<b>Example:</b>	AXIS2:CCW
Scan	
<b>Command:</b>	SCAN
<b>Description:</b>	Instructs the positioner to begin scanning between preset lower and upper limits.
<b>Example:</b>	AXIS1:SCAN
Seek Negative	
<b>Command:</b>	SKN <nnn.n>
<b>Description:</b>	Instructs the device to begin seeking the specified target value in the negative (down/counterclockwise) direction only. This command primarily supports continuous rotation mode. It allows forcing seeking a position from a particular direction. Thus, a SKN from 180.0 to 181.0 will rotate counterclockwise to reach the target value. In non-continuous rotation mode if the target is up/clockwise from the current position, no motion occurs. The target must be located between the current upper/clockwise and lower/counterclockwise limits.
<b>Example:</b>	AXIS1:SKN 30
Seek Position	
<b>Command:</b>	SK nnn.n
<b>Description:</b>	Instructs the device to begin seeking for a target position. In continuous rotation mode, the device will seek the target value by the shortest possible path. Thus, a seek from 350.0 to 10.0 will rotate clockwise, not direction.
<b>Example:</b>	AXIS1-2:SK 90,30
Seek Positive	
<b>Command:</b>	SKP <nnn.n>
<b>Description:</b>	Instructs the device to begin seeking the specified target value in the position (up/clockwise) direction only. This command is provided primarily to support continuous rotation mode. It allows forcing seeking a position from a particular direction. Thus, a SKP from 181.0 to 180.0 will rotate clockwise to reach the target value. In non-continuous rotation mode if the target is down/counterclockwise from the current position, no motion occurs. The target must be located between the current upper/clockwise and lower/counterclockwise limits.
<b>Example:</b>	AXIS2:SKP 90

Seek Relative	
<b>Command:</b>	SKR [+ -]nnn.n
<b>Description:</b>	Instructs the device to begin seeking the specified target value relative to the current position. The specified value is added to the current position to obtain the target position. Thus, a positive value will cause up/clockwise motion and a negative value will cause down/counterclockwise motion.
<b>Example:</b>	AXIS1-2:SKR -10,10

Speed																			
<b>Command:</b>	Sn Where n is a number between 1 and 8. The factory speed settings configuration is: <table border="1"> <thead> <tr> <th>Setting</th> <th>Deg/s</th> </tr> </thead> <tbody> <tr><td>1 -</td><td>0.35</td></tr> <tr><td>2 -</td><td>0.70</td></tr> <tr><td>3 -</td><td>1.05</td></tr> <tr><td>4 -</td><td>1.22</td></tr> <tr><td>5 -</td><td>1.40</td></tr> <tr><td>6 -</td><td>1.56</td></tr> <tr><td>7 -</td><td>1.74</td></tr> <tr><td>8 -</td><td>2.10</td></tr> </tbody> </table>	Setting	Deg/s	1 -	0.35	2 -	0.70	3 -	1.05	4 -	1.22	5 -	1.40	6 -	1.56	7 -	1.74	8 -	2.10
Setting	Deg/s																		
1 -	0.35																		
2 -	0.70																		
3 -	1.05																		
4 -	1.22																		
5 -	1.40																		
6 -	1.56																		
7 -	1.74																		
8 -	2.10																		
<b>Description:</b>	Changes the device speed																		
<b>Query:</b>	S?																		
<b>Returns:</b>	A number between 1 and 8																		
<b>Example:</b>	S3 Set AXIS1 current speed to 1.05 deg/s																		

Speed Preset					
<b>Command:</b>	SS<n> <speed>				
<b>Description:</b>	Assigns a preset speed setting 0-255 to n, where n is a number 1-8. <b>Warning:</b> There can be no white space between the command and the register number. However, there must be white space between the register number and the speed value.				
<b>&lt;speed&gt;</b>	Value from 0-255 representing the desired speed setting for the specified speed selection. A value of 0 represents the minimum available speed of the device. A value of 255 represents the maximum speed of the device. The actual speed of the device is given approximately by the formula: $\text{Actual Speed} = (\text{MaxSpeed} - \text{MinSpeed}) / 255 + \text{MinSpeed}$ For Axis 1, 2, and 3: Min Speed = .18 deg/s Max Speed = 2.45 deg/s				
<b>Query:</b>	SS#?				
<b>Returns:</b>	Value between 0 (minimum) and 255 (maximum) speed.				
<b>Example:</b>	<table border="0"> <tr> <td>SS2 127</td> <td>Set speed 2 to half speed</td> </tr> <tr> <td>SS5 63</td> <td>Set speed 5 to quarter speed</td> </tr> </table>	SS2 127	Set speed 2 to half speed	SS5 63	Set speed 5 to quarter speed
SS2 127	Set speed 2 to half speed				
SS5 63	Set speed 5 to quarter speed				

Stop Motion	
<b>Command:</b>	ST
<b>Description:</b>	Causes device motion to stop.
<b>Example:</b>	AXIS1-2:ST

Trigger Configuration	
<b>Command:</b>	TRIGGER (<ON OFF>, <step size>,<reference>,<pre trigger delay>, <pulse length>,<post trigger delay>,<polarity>)
<b>Description:</b>	Use this command to configure the trigger. Where step size is the angular distance between trigger pulses in degrees, reference position is one of the positions where a trigger should occur (not necessarily a starting position), pre-trigger delay is the time between reaching the target encoder position and producing a trigger pulse, trigger pulse length is the active period of the trigger pulse, post trigger delay is the minimum inactive period after the trigger pulse before another trigger event can occur, and High/Low sets the polarity of the trigger signal. Time unit is milliseconds.
<b>Query:</b>	TRIGGER?
<b>Returns:</b>	Trigger configuration
<b>Example:</b>	TRIGGER (ON,15.00,0.00,0.10,1.00,0.00,LOW)

Upper Limit	
<b>Command:</b>	UL nnn.n
<b>Description:</b>	Sets the upper/clockwise limit of the device. The specified value nnn.n must be greater than the lower/counterclockwise limit.
<b>Query:</b>	UL?
<b>Returns:</b>	Upper or clockwise limit of the device in degrees.
<b>Example:</b>	AXIS2:UL 90

## **Error Codes**

- 1 – Controller board Flash memory malfunction
- 2 – Axis not moving
- 3 – Motor not stopping
- 4 – Motor moving on wrong direction
- 5 – Hardware Limit hit
- 6 – Polarization limit violation
- 7 – Lost communication
- 9 – Encoder failure
- 10 – Trigger failure
- 11 – Motor overheat
- 12 – Relay failure,
- 13 – Position out of bounds
- 14 – Trying to move a locked axis
- 32 – Motor driver fault
- 100-399 – Command syntax error
- 400-499 – Home procedure failure
- 500-599 – Trigger command malformed
- 1000- – Firmware upgrade failure

# NETWORK CONFIGURATION

## Network Factory Configuration

- IP Address.....: 192.168.0.100
- Net Mask.....: 255.255.255.0
- Gateway.....: 192.168.0.1
- Command Port...: 1206

## Changing the Positioner IP Address

In a Local Area Network (LAN), there cannot be more than one device using the same IP address. The IP address of the device will need to be changed if more than one device is in the same (LAN). To change the IP address of an ETS-Lindgren Ethernet device, use its embedded web page.


1. Point your browser to 192.168.0.100 or the address you have previously set your device to.
2. Type the new IP address as highlighted below and click 'SET'.

The screenshot shows a web browser window titled "ETS-L Positioner" with the address bar displaying "192.168.0.100". The page content includes the ETS-LINDGREN logo and the title "Positioner". Below the title is a "Command List" section with three main panels: "System", "Position", and "Command". The "System" panel contains fields for "Device" (Positioner), "IP Address" (192.168.0.100), and "Firmware" (6.02 May 28 2021 14:30:47 PCA120518). The "IP Address" field is highlighted in yellow. The "Position" panel shows "Axis 1", "Axis 2", and "Axis 3" all set to 0.0. The "Command" panel is set to "AXIS1" and contains various control buttons like "Speed Preset", "Acceleration", "Lower Limit", "Upper Limit", "Position", "Seek Relative", "Home", "Zero", "Move", "Enter/Exit Cont. Rot.", "Scan", and "Stop Movement". The "Trigger" panel at the bottom shows settings for "State" (OFF), "Step (Deg)" (15.00), "Pre Delay (ms)" (10.00), "Pulse Width (ms)" (1.00), "Post Delay (ms)" (10.00), and "Polarity" (LOW). The footer of the page contains the copyright notice "© 2021 by ETS-Lindgren Inc. All rights reserved." and the code "(ALP 2/1/21)".

A second method for resetting the IP configuration of the device is to connect to the device using any TCP/IP capable terminal application, and sending commands to it. PuTTY is a terminal emulator available for use. PuTTY is a free (MIT licensed) Windows Telnet and SSH client and can be downloaded from <https://www.putty.org/>.

Run PuTTY, and point it to Host 192.168.0.100 Port 1206. Then set Connection type to Raw and click Open.

Ensure the connection is working by typing \*IDN? then pressing the Enter key on the keyboard. The device will respond with an identification string such as the one shown below.



The IP address can be changed using the **MOD:IP** command. To check the current IP address by typing **MOD:IP?**

To change the IP address to 192.168.0.200, type **MOD:IP 192.168.0.200** and press the Enter key on the keyboard. The device will set the new address and reset the connection.

## Reset to Factory Default

To reset configuration, press the reset button for at least 6 seconds. It will reset the IP address back to factory configurations, 192.168.0.100, Mask = 255.255.255.0.

If your positioner does not have a reset button, please follow these instructions to reset the network configuration,

Start with the device powered off for at least 5 seconds

1. Turn the device ON for 5 seconds
2. Turn the device OFF for 5 seconds
3. Turn the device ON for 5 seconds
4. Turn the device OFF for 5 seconds




5. Turn the device ON for 5 seconds
6. Turn the device OFF for 5 seconds
7. Turn the device ON for 5 seconds
8. Turn the device OFF for 5 seconds
9. Turn the device ON for 5 seconds
10. Turn the device OFF for 5 seconds

Make sure you wait 5 seconds between power cycles.

This reset procedure only works on devices running on firmware version 5.7 or later

## Computer Network Configuration

Connect to an ETS-Lindgren Ethernet by setting the computer Ethernet interface to the selections shown below.




## Background Information

Preparing a computer for connection is relatively simple if you have an Ethernet adapter installed. An Ethernet adapter, also called a network card, network interface card, or network interface controller, provides a physical port for networking mediums such as Ethernet cables. It also communicates with the computer and allows it to access a network device.


Follow these steps on a Windows 10 PC to configure the Ethernet adapter.

1. Verify that the Ethernet adapter is installed:
  - a. Open Device Manager.
  - b. Select "Network adapters."
  - c. Right-click the network adapter.
  - d. Click "Properties." The information in the "Properties" window will indicate whether or not your Ethernet adapter is installed and working.




## 2. Configure the Ethernet Adapter


- a. In Windows, click into the Start toolbar.
- b. Type “change Ethernet settings.”
- c. In the search results, click “change Ethernet settings.”
- d. In the Settings window, click “Change adapter options.”



- e. Right click on the Ethernet adapter you intend to configure, and select “Properties.” (Ensure you are logged into an administrator account to change the configuration.)



- f. Select "Internet Protocol Version 4 (TCP/IPv4)", then click "Properties". Select "Use the following IP address", then enter the addresses as follows:  
 IP address: 192.168.0.1  
 Subnet mask: 255.255.255.0  
 Default gateway: blank
- g. Select "Use the following DNS server addresses" and leave Preferred and Alternate DNS server fields blank.
- h. Click OK.



Information about subnet mask can be found online at the following two locations:

<https://www.iplocation.net/subnet-mask>

<https://searchnetworking.techtarget.com/definition/subnet>

## Multiple Devices in a LAN

When using more than one positioner, there is no need for a separate server for each positioner. An Ethernet switch can be used to connect as many devices as necessary to a single computer. Such a configuration requires each device have a unique IP address. If using more than one positioner in a LAN, change the device's IP address. Point your browser to the device (192.168.0.100) and set a new IP address.

Multiple Device LAN

