

EMPower™ Power Meter

Model 7002-006

Product Manual



Copyright and Trademark

ETS-Lindgren Inc. reserves the right to make changes to any products herein to improve functioning or design. Although the information in this document has been carefully reviewed and is believed to be reliable, ETS-Lindgren does not assume any liability arising out of the application or use of any product or circuit described herein; nor does it convey any license under its patent rights nor the rights of others. All trademarks are the property of their respective owners.

© Copyright 2018–2024 by ETS-Lindgren Inc. All Rights Reserved. No part of this document may be copied by any means without written permission from ETS-Lindgren Inc.

Trademarks used in this document: The ETS-Lindgren logo is a registered trademark, and EMCenter, EMPower, TILE!, and EMQuest are trademarks of ETS-Lindgren Inc.

Revision Record

MANUAL, EMPOWER METER, 7002-006 | Part #1679937, Rev. C

Revision	Description	Date
A	Initial Release	MAY, 2018
B	Updated format	SEP, 2022
C	Update	FEB, 2024

Safety Information



ONLY QUALIFIED PERSONNEL should operate or service this equipment.



Waste Electrical and Electronic Equipment (WEEE) Directive: (European Union) At end of useful life, this product should be deposited at an appropriate waste disposal facility for recycling and disposal. Do not dispose of with household waste.

Notes, Cautions, and Warnings



Note: Denotes helpful information intended to provide tips for better use of the product.



CAUTION: Denotes a hazard. Failure to follow instructions could result in minor personal injury and/or property damage. Included text gives proper procedures.



WARNING: Denotes a hazard. Failure to follow instructions could result in **SEVERE** personal injury and/or property damage. Included text gives proper procedures.

Table of Contents

Copyright and Trademark	ii
Revision Record	ii
Safety Information	iii
Notes, Cautions, and Warnings	iii
Table of Contents	4
Introduction	6
Standard Configuration	6
ETS-Lindgren Product Information Bulletin	7
Functional Description	7
CW Mode	7
Peak Mode	7
Envelope Tracing	7
Burst Mode	8
Operation	10
Installation	10
Hardware and Software Configuration	10
Standalone Control	10
Remarks about the General Commands	11
Remarks about Burst Mode	12
Default Values	12
Maintenance	14
Fiber Optic Maintenance	14
Service Procedures	14
Contacting ETS-Lindgren	14
Replacement and Optional Parts	15
Sending a Component for Service	15
Calibration Services and Annual Calibration	15
Upgrade Policies	15
Specifications	16
Electrical	16
Power Consumption	17
Interfaces	17
Mechanical	17

Environmental Conditions.....	17
Filter Setting: Number of Samples used for RMS Calculation	18
Appendix A: Warranty	19
Duration of Warranties.....	19
Appendix B: EC Declaration on Conformity.....	20

Introduction

The EMPower is a RF power meter especially designed for power measurements during EMC tests.

The EMPower RF power sensor is mounted in a rugged metal housing to ensure a long life and excellent RF shielding. The power sensor is equipped with an N- type precision RF input connector and a mini USB- B connector for communication with a computer.

In addition to the USB interface, the EMPower can be controlled by both the EMPower Viewer integral EMC measurement software and any other EMC measurement packages, because all the software codes needed to control the unit are available.

For 'stand-alone use' of the EMPower, EMBurst Data Acquisition software is delivered with the system. By using the USB1004A plug-in card, up to four EMPower heads can be connected to a single plug-in card in an EMCenter.

In combination with EMPower Viewer, the 7002-006 can be used to perform simultaneous power measurements on multiple ports of MIMO devices in accordance with EN 300 328. All necessary parameters are calculated by EMPower Viewer.

Standard Configuration

The EMPower is delivered with the following items:

- **EMPower RF Power Sensor**
 - Model: 7002-006
- **Shielded USB Cable**
 - Model: USB A male to mini USB B male
 - For connecting the RF power sensor with the plug-in card
- **Trigger cable**
 - For measurements on multiple ports



ETS-Lindgren Product Information Bulletin

See the ETS-Lindgren *Product Information Bulletin* included with your shipment for the following:

- Safety, regulatory, and other product marking information
- Steps to receive your shipment
- Steps to return a component for service
- ETS-Lindgren calibration service
- ETS-Lindgren contact information

Functional Description

The EMPower uses a high-speed RMS power detector to measure the RF signal, independent of the crest factor of the input signal waveform. The detected signal is sampled, at high speed, by a high speed ADC and the samples are processed by a powerful DSP. The sophisticated software enables unique functions, such as burst logging.

CW Mode

The EMPower performs RMS power measurements of CW-signals. In RMS mode the EMPower samples the signal at high speed. The RMS value of the power is calculated over the number of samples defined by the filter setting and can be read by a simple command. Due to the high sampling speed, the number of readings is high, even at large filter settings.

Peak Mode

The EMPower performs peak measurements (max hold) on RF-signals. In peak mode, the EMPower keeps track of the highest level that has been measured. This can be done for an infinite time. Once the power level has been read, the maximum value is automatically reset.

Envelope Tracing

The EMPower captures the envelope of an RF-signal. This unique feature enables the possibility to visualize, for example, the inrush phenomena of transmitters or signal generators, without the need for an expensive RF analyzer. Due to the extensive trigger possibilities, almost any RF-signal can be captured in the large buffers of the EMPower.

Burst Mode

The EMPower logs RF-bursts of a wide variety of RF standards, including LTE, WiMAX, W- CDMA, CDMA2000, TD-SCDMA, and EDGE. For these complex transmitters, such as WLAN devices, a special burst mode has been implemented.

During the observation time, the time and RMS power of each RF-burst is logged into memory. These measurements can be used to perform conducted measurements of RF output power, according to the latest version of the ETSI EN 300 328 standard.

Parameters such as medium utilization, Tx-gap and Tx- sequence are automatically calculated and displayed on the PC screen by EMBurst Data Acquisition software.

The EMPower is equipped with a trigger in- and output to enable simultaneous measurements on multiple ports of MIMO devices. By daisy chaining the trigger signal of the 7002-006, multiple power meters can be synchronized using EMBurst Data Acquisition software.

Theory of Operation in Burst Mode

The 7002-006 is especially designed for (MIMO) measurements according to EN 300 328. For this purpose, the power meter is equipped with a RMS responding power detector.

The power of the RF signal in an equivalent decibel-scaled value is precisely converted into DC voltage on a linear scale, independent of the crest factor of the input signal waveforms. This DC voltage is translated to a power value in dBm or Watts, based on the frequency of the RF signal. Therefore, each sample measured by the 7002-006 represents the RMS power.

The sample speed in burst mode can be set to 1 MSps or 5 MSps. All samples within a RF burst are calculated by the power meter according to:

$$P_{burst} = \frac{1}{m} \sum_{n=1}^m P_{sample}(n) \text{ [W]}$$

Where m is the number of RMS power samples within the start and stop time of the RF burst. These times are defined as the points where the power is at least 30 dB below the highest value of the measured samples. This value (threshold level) can be set in EMBurst Data Acquisition software. For each RF burst, the RMS power, start time and stop time is stored in the power meter.

For MIMO measurements using multiple 7002-006 power meters, the total RF power of a burst is calculated using for example EMBurst Data Acquisition

software. The burst data of each power meter is gathered by EMBurst Data Acquisition software and calculated to a total power of the RF burst according to the formula:

$$P_{burst, total} = \sum_{i=1}^j P_{burst}(i) \text{ [W]}$$

Where j is the number of 7002-006 power meters of the MIMO test setup. Corrections like coupler values as well as beamforming gain (Y) and the assembly gain (G) of the DUT can be added in EMBurst Data Acquisition software and will be accounted for in the results of the total power of the bursts.

Operation

Installation



CAUTION: Before connecting any components, follow the safety information in the ETS-Lindgren *Product Information Bulletin* included with your shipment.

Hardware and Software Configuration

1. Connect the EMPower sensor to a Windows computer with a USB 1.1 compatible port. Use the supplied USB cable to connect the EMPower sensor.
2. Windows will prompt that new hardware has been found. The USB-driver for the EMPower is Windows certified and will be loaded automatically from the Windows update.
3. If the drivers are not loaded automatically, these can be installed manually from the supplied USB-key. Follow the normal instructions from Windows to install the drivers manually.
4. Once the drivers are loaded successfully, the EMPower will be shown in the device list.
5. The installation for the EMPower sensor is now complete. The user can control the EMPower using the EMBurst Data Acquisition software.

Standalone Control

The EMPower uses a high-speed communication protocol that is supported by EMPower Viewer™. This results in short transfer times of the data, even at long observation times or large numbers of samples.

As a result, a simple terminal program cannot be used to communicate with the EMPower directly. The EMPower uses a USB2.0 FTDI transceiver with a D2XX driver for Windows. Programmers can use the functions that are supported by the D2XX driver to read from, and write data to, the EMPower to design their own driver for other automation software.

Remarks about the General Commands



To use the EMPower-006 remote commands, read the [manual document 399342 EMCenter](#) for examples and a full command list.

In RMS mode, a new power measurement is started after the “power?”-command has been given. Depending on the filter setting, the EMPower performs the required number of measurements and returns the average value of all linear power samples.

Acquisition speed, filter and VBW settings are important to obtain accurate measurements for power measurements of AM modulated signals. In general, the VBW should be 10 times smaller than the RF carrier frequency, but higher than the modulation frequency. For example if an AM modulated signal is measured with a modulation frequency of 1 kHz, the VBW should be set to 10k or higher.

The acquisition speed and filter should be set in such a way that at least one full period of the modulation signal is measured. At 1 Msps, the filter should be set to 5 or higher, which results in 1000 or more samples being averaged. At lower sampling speeds, for example 100 ksps, the filter should be set to 3 or higher to cover at least one full period of the envelope signal.

In formula:

$$\text{Filter bandwidth} = \frac{\text{Acquisition speed}}{\text{number of averages}} \ll \text{modulation frequency}$$

While:

$$\text{Modulation frequency} \ll \text{VBW} \ll \text{Carrier frequency}$$

In PEAK mode, the “power?”-command will return the highest value measured, since the previous “power?”-command. After reading the power, the stored value will be cleared.

The filter setting does not apply in peak mode, envelope tracing, or burst mode.

The VBW setting can be different for RMS mode and the other modes. If a VBW has been set for RMS mode, this will not affect the VBW setting for the other modes and vice versa. VBW command does not apply for the burst mode (7002-006), since this model has no video filter.

Power measurements will be interrupted if a temperature reading is requested.

The STORE command stores all settings in flash memory. All parameters mentioned in the table in chapter 5.2 (default values) are stored.

During Envelope Tracing, temperature readings are not updated as long as the trigger is armed. While armed, temperature readings are still possible, but the actual values are taken before the measurement is armed. As soon as a trigger occurs, the temperatures are updated in the sensor.

Remarks about Burst Mode

In burst mode, the EMPower can store the information of 100.000 bursts independent of the observation time. For each burst, the RMS power and start/stop-times are stored in the buffers. The sample speed can be set to 1 MS/s or 5 MS/s to ensure correct measurements according to the ETSI standard for wideband devices.

In MIMO measurements, using multiple synchronized EMPower meters, EMPower ViewerTM captures samples simultaneously and calculates the total power according to the EN 300 328 standard.

Default Values



Note: The following table shows the default values for the EMPower. Use the “RESET” command to return to these factory defaults values:

Command	Default value	Description
MODE	0	RMS power measurement
AUTO_STORE	0	Parameter changes will not be stored automatically
FREQUENCY	1300000 kHz	1300 MHz
FILTER	AUTO	Automatic filter setting (related to power level)
POWER_OFFSET	0.00	Sets power offset to 0.00 dB
POWER_UNIT	0	Sets measurement unit to dBm
VBW (mode 0)	1k	1kHz VBW in RMS mode for CW signals.
VBW (mode 1, 2 and 3)	AUTO	Automatic VBW setting for all other modes.

ACQ_SPEED	1000	1 MSps
ACQ_LOG_THRESHOLD	-40.0	-40 dBm
ACQ_LOG_TRIG_TYPE	0,1	Internal triggering, rising edge
ACQ_LOG_TRIG_SET	1,2	2 samples with 2 samples distance for evaluation
ACQ_AUTO_TRIGGER	0	Single trigger
ACQ_LOG_DELAY	0	No delay time before trigger
ACQ_LOG_TRIG_HOLDOFF	0	No hold off before trigger
BM_MEASURE_PERIOD	60000	60000 ms
BM_NOISE_TIMER	10	10 samples
BM_TRIG_LEVEL	-40	-40 dBm

Maintenance



CAUTION: Before performing any maintenance, follow the safety information in the ETS-Lindgren *Product Information Bulletin* included with your shipment.



WARNING: Maintenance of the EMCenter is limited to external components such as cables or connectors. If you have any questions concerning maintenance, contact ETS-Lindgren Customer Service.



If you have any questions concerning maintenance, contact ETS-Lindgren Customer Service.

Fiber Optic Maintenance

Fiber optic connectors and cables can be damaged from airborne particles, humidity and moisture, oils from the human body, and debris from the connectors they plug into. Always handle connectors and cables with care, using the following guidelines.



CAUTION: Before performing any maintenance, disconnect fiber optic cables from the unit and turn off power.

- When disconnecting fiber optic cables, apply the included dust caps to the ends to maintain their integrity.
- Before connecting fiber optic cables, clean the connector tips and in-line connectors.
- Before attaching in-line connectors, clean them with moisture-free compressed air.
- Failure to perform these tasks may result in damage to the fiber optic connectors or cables.

Service Procedures

Contacting ETS-Lindgren



Note: Please see www.ets-lindgren.com for a list of ETS-Lindgren offices, including phone and email contact information.

Replacement and Optional Parts



Note: ETS-Lindgren may substitute a similar part or new part number with the same functionality for another part/part number. Contact ETS-Lindgren for questions about part numbers and ordering parts.

Part Number	Part Description
7006-001	EMControl™ Positioner Controller Plug-In Card

Sending a Component for Service

For the steps to return a system or system component to ETS-Lindgren for service, see the *Product Information Bulletin* included with your shipment.

Calibration Services and Annual Calibration

See the *Product Information Bulletin* included with your shipment for information on ETS-Lindgren calibration services.

Upgrade Policies

Periodically, field probes are upgraded to enhance functionality. Contact ETS-Lindgren Customer Service for the upgrade status of your field probe.

Specifications

Electrical

Detector type	RMS detector
Measuring function	RMS CW power, Peak power Burst mode
Frequency range	10 MHz to 6 GHz
Power measuring range	-50 to + 10 dBm
Input damage level	> +20 dBm
Resolution	0.01 dB
RF input connector	Precision N-type
RF input impedance	50 Ohm
Max SWR: < 100 MHz	1.10
100 MHz to 1 GHz	1.10
1 GHz to 6 GHz	1.15
Frequency response accuracy (at 23° C ± 2° C)	+/- 0.2 dB
Deviation from CW for signals with high Crest factor	< 0.2 dB
Linearity error	0.05 dB + 0.005 dB/dB
Temperature effect	0.15 dB max over full temperature range
Measuring units	dBm or Watts
Zero adjustment	Not required
Frequency response correction	Stored frequency response data is taken into account by numerical entry of the measurement frequency
Measurement speed	10, 50, 100 kS/s, 1, 5, 10, 20, 40 MS/s
Storage capacity	100,000 samples

Power Consumption

Supply voltage	+5VDC from USB port (4.75 V to 5.25 V)
Current consumption (USB)	Max. 200 mA

Interfaces

Communication	USB 1.0 (drivers supplied for Windows XP and Windows 7)
----------------------	---

Mechanical

Dimensions of measuring device	124 * 32 * 32 mm
RF input connector	N type precision
Data connector (power head side)	USB mini type B
Trigger input and output	MMCX
EMCenter	USB1004A plug-in card

Environmental Conditions

Temperature range (operating)	0° to 40° Celsius
Temperature range (storage)	-20 to 85° C
Relative humidity	10 – 90% (non-condensing)

Filter Setting: Number of Samples used for RMS Calculation

RMS (Mode 0)	Number of samples
Filter 1	10
Filter 2	30
Filter 3	100
Filter 4	300
Filter 5	1000
Filter 6	3000
Filter 7	5000
Auto filter mode	Number of samples
+10 to 0 dBm	100 (filter 3)
0 to -10 dBm	100 (filter 3)
-10 to -20 dBm	100 (filter 3)
-20 to -30 dBm	300 (filter 4)
-30 to -40 dBm	1000 (filter 5)
-40 to -50 dBm	3000 (filter 6)
Below -50 dBm	5000 (filter 7)

Appendix A: Warranty



Note: See the *Product Information Bulletin* included with your shipment for information for the complete ETS-Lindgren warranty.

Duration of Warranties

All product warranties, except the warranty of title, and all remedies for warranty failures are limited to three years.

Product Warranted	Duration of Warranty Period
EMPower Power Meter 7002-006	3 Years

Appendix B: EC Declaration on Conformity

ETS-Lindgren Inc. declares these products to be in conformity with the following standards and provisions:

Product **EMPower™ USB RF Power Sensor**
Models:

Directives: EMC Directive 2014/30/EU
Low Voltage Directive 2014/35/EU
RoHS Directive: 2015/863/EU

Emission: EN 61326-1:2013, Class A1
Electrical equipment for measurement, control and laboratory use.

Immunity: EN 61326-1:2013, Industrial level, performance criteria A
Electrical equipment for measurement, control and laboratory use.

Safety: EN 61010-1:2010, Safety requirements for electrical equipment
for measurement, control, and laboratory use.

Technical Construction Files are available upon request.